



42 Edgewood Drive  
Holland, NY 14080  
www.ecostarllc.com

## SENECA SHAKE™ TILES ECOSTAR GOLD STAR ROOF SYSTEM

	<u>PAGE</u>
<b>Part 1 – GENERAL</b>	
1.01 Description	2
1.02 Quality Assurance	2
1.03 Submittals	3
1.04 Product Delivery, Storage and Handling	3
1.05 Job Conditions (Cautions and Warnings)	3
1.06 Warranty	3
<b>Part 2 – PRODUCTS</b>	
2.01 General	4
2.02 Tile	4
2.03 Related Materials	4
<b>Part 3 – EXECUTION</b>	
3.01 Substrate Criteria	5
3.02 Substrate Preparation	5
3.03 Installation	5

# SENECA SHAKE TILES ECOSTAR GOLD STAR ROOF SYSTEM

## PART 1 – GENERAL

### 1.01 DESCRIPTION

- A. Furnish and install Seneca Shake Tile roofing system as specified in the Contract Documents and roof plan.
- B. Furnish and install this Seneca Shake Tile Roof System in strict accordance with specifications and drawings approved by EcoStar.
- C. Related Work
  - 1. Metal flashing work is not covered in this specification since EcoStar does **NOT** warrant metal flashing. EcoStar advises that metal flashing and securement of metal should be to industry standards (SMACNA) to prevent the metal from pulling free or buckling. EcoStar also suggests that all flashing metal be stainless steel or copper (see 3.03D).
  - 2. EcoStar EcoVent™ ridge ventilation product must be used on those projects that will be using a ridge ventilation system. If a ridge ventilation system is not to be used on the project, another form of ventilation may be used, but will not be covered by any EcoStar warranties. EcoStar advises that a ridge style venting system be utilized to insure the best possible air movement and to provide the best aesthetic appearance to the roofing system.

### 1.02 QUALITY ASSURANCE

- A. To qualify for an EcoStar Gold Star warranty, an authorized EcoStar Gold Star applicator must install system.
- B. There shall be no deviation made from this specification without written approval from EcoStar prior to the start of the roofing project.
- C. For an EcoStar Gold Star warranty, upon completion of the installation, an inspection must be conducted by a field service representative of EcoStar to ascertain that the roofing system has been installed according to EcoStar's published specifications and details at time of bid. This inspection is not intended to be a final inspection for the benefit of the owner, but for the benefit of EcoStar to determine whether a warranty shall be issued.
- D. It is the authorized Gold Star roofing applicator's responsibility to adhere to all applicable building codes (local and national) and to have or acquire the appropriate licenses and permits for the roofing system installation requirements and limitations in their local areas.
- E. Specific testing requirements:
  - 1. Class A & C Fire Resistance – UL 790 Test Standard
  - 2. Class 4 Impact Resistance – UL 2218 Test Standard

### 1.03 SUBMITTALS

- A. Submit an "EcoStar Gold Star Project Survey" to EcoStar technical department for approval **PRIOR** to project bid to enable the technical department to approve and assign a job number to the project.

1. The "EcoStar Gold Star Project Survey Form" must be filled out completely and accurately to include any prior deviations approved from this specification, including a roof drawing showing all dimensions, all penetrations, and roof slope.
- B. When an EcoStar Gold Star Warranty is desired, EcoStar must be contacted **PRIOR** to project bid and installation. Information will be required for wind speeds greater than 70 mph and deviation to standard slope requirements.

#### **1.04 PRODUCT DELIVERY, STORAGE AND HANDLING**

- A. Deliver materials in original unopened packages.
- B. Packages shall be labeled with manufacturer's name, brand name and identification of various items.
- C. All tile materials must be stored above 45°F. If exposed to lower temperatures, restore project temperature to 45°F minimum before using.
- D. Store all materials in a dry protected area. Damaged materials must **NOT** be used. Installed materials found to be damaged shall be replaced at Gold Star Authorized Applicator's expense.

#### **1.05 JOB CONDITIONS (CAUTIONS AND WARNINGS)**

- A. Contact the EcoStar technical department for procedures when installing a Seneca Shake Tile roof system during temperatures lower than 45°F.
- B. Do not install the Seneca Shake Tile roof system directly over existing asphalt shingles or existing tile roof systems. All existing roof materials **MUST** be removed prior to installation of the Seneca Shake Tile Roof System.
- C. Roofing surface must be free of ice, water, or snow prior to and during the roofing project.
- D. Decking materials must be dimensionally stable prior to installing the Seneca Shake Tiles. If the materials are not dry, EcoStar recommends installing the underlayment and allowing the roof to dry out before installing Seneca Shake Tiles.

#### **1.06 WARRANTY**

- A. EcoStar will provide the Gold Star warranty for those materials supplied by EcoStar when an authorized EcoStar Gold Star applicator completes the project and all required materials have been utilized within the roof system.
- B. Only when an EcoStar technical representative has inspected and approved the completed installation will an EcoStar Gold Star warranty be issued.
- C. The warranty is available for most types of buildings and structures.
- D. The warranty period is expressed on the warranty certificate, which reflects the inclusive dates of coverage.
- E. The warranty does **NOT** cover the aesthetic appearance of the Seneca Shake Tiles. Care should be taken by the EcoStar authorized Gold Star applicator to insure that proper blending of the tiles occurs. When improper blending occurs, the aesthetic appearance of the roof can be affected negatively. **All** materials required for job completion should be on site to blend from.

## PART 2 – PRODUCTS

### 2.01 GENERAL

All components of the Seneca Shake Tile Roof System are to be products manufactured or supplied by EcoStar LLC

NOTE: Only products supplied by EcoStar LLC are included in the warranty unless otherwise specified and approved in writing by EcoStar LLC.

### 2.02 TILES

- A. Seneca Shake Tiles are made of **Starloy™**, an 80% recycled rubber and plastic compound with appropriate colorants and UV stabilizers, at 6", 9", & 12" widths by 19" long, and with a tapered nominal thickness of 3/8". Weight shall be determined by the following acceptable tile exposures:
- 8" = 220 – 235 lbs per square
  - 7-1/2" = 235 – 251 lbs per square
  - 7" = 251 – 269 lbs per square
- B. Seneca Plus Shake Tiles made of **Starloy™**, an 80% recycled rubber and plastic compound with appropriate colorants and UV stabilizers, at 6", 9", & 12" widths by 19" long, and with a tapered nominal thickness of 3/8". Weight shall be determined by the following acceptable tile exposures:
- 8" = 307 – 325 lbs per square
  - 7-1/2" = 329 – 347 lbs per square
  - 7" = 351 – 370 lbs per square
- C. Seneca and Seneca Plus Shake Tiles color selection shall be made prior to bid opening and shall conform to one of the following colors:
- Black       Midnight Gray       Federal Gray       Smoke Gray       Earth Green
  - Stone Red       Mountain Plum       Cedar Brown       Chestnut Brown       Sage Green

### 2.03 RELATED MATERIALS

- A. Underlayment
1. AquaGuard – a roofing underlayment recognized for use as an alternative to Type 30 roofing underlayment, consisting of spunbonded polyolefin coated with a layer of UV stabilized polyolefin on both sides, meeting requirements of ASTM D2626, referred to as 30 lb. and without perforations.
  2. Glacier Guard™ ice & water underlayment – Granular Surface 100 (55-mil), Smooth Surface 200 (55-mil), or Smooth Surface High Temperature 300 or Smooth Surface 400 (40-mil), a composite membrane consisting of fiberglass-reinforced rubberized asphalt laminated to an impermeable polyethylene film layer (Smooth Surface & Smooth Surface High Temperature) or coated with a granular surface providing maximum skid resistance (Granular Surface).
  3. ELK Versashield® - ELK VersaShield underlayment must be installed over the entire deck surface including over the Glacier Guard in conjunction with EcoStar UL Class A Seneca Shake tiles for those roof applications requiring UL Class A fire rating. ELK VersaShield should be installed per manufacturer's specifications.

## B. Fasteners

### 1. AquaGuard

- a. Roofing nails with one inch (1") diameter round or square head, plastic or metal, and 3/4" long shank. Metal parts of fastener are to be corrosion resistant.

### 2. Tile Fasteners

- a. EcoStar ring shank roofing nail with a 3/8" diameter head and a minimum of 1-1/2" long shank made from stainless steel. Nails can be supplied either as a hand drive style or in coils for use in pneumatic tools. The EcoStar ring shank nail is required for fastening all EcoStar roof tiles.

**NOTE:** EcoStar roofing nails when used in the Seneca Shake roof system are included in the EcoStar warranty.

## PART 3 - EXECUTION

### 3.01 SUBSTRATE CRITERIA

- A. The Building owner or owner's representative is responsible for providing and determining that the substrate is suitable to receive the Seneca Shake Tile roof system and the authorized EcoStar Gold Star applicator should not proceed until all defects have been corrected.
- B. The Seneca Shake roof system may only be applied over
  1. Minimum 1/2" plywood or 7/16" OSB decking, properly gapped for expansion.
  2. Minimum 1" tongue and groove wood decking with end gaps not exceeding 1/4", and board widths not exceeding 6 inches.
  3. Approved metal deck systems – (Metal deck systems will require the installation of appropriate thickness nail base insulation prior to attaching the EcoStar tiles) Contact EcoStar technical department for specifics.
  4. Appropriate clearance on underside of decking or sheathing must be provided for proper penetration of the EcoStar fastener.
- C. Minimum slope of substrate for installation of Seneca Shake roof system shall be a minimum of 3/12 for 7" exposure installation and a minimum of 6/12 for 8" exposure installation. Contact the EcoStar technical department for approval of applications on lower slopes or exceptions to this requirement.

### 3.02 SUBSTRATE PREPARATION

- A. The building owner or owner's representative is responsible for ensuring that all wet or damaged substrate has been removed in a re-roofing application.
- B. Existing roof material **MUST** be removed and a clean substrate free of foreign material be provided prior to the installation of the Seneca Shake Tile roof system. Seneca Shake Tiles may **NOT** be installed directly over any existing roof material or system.

### 3.03 INSTALLATION

- A. Flashing & Sheet Metal – Install sheet metal and flashing metal in all valleys and where required. EcoStar recommends a V-type W type or double W type metal valley flashing be used at all valleys.
- B. Where required, install metal edging at all eaves and roof edges.
- C. EcoStar suggests that all metal work be made from stainless steel. Final choice of metal flashing is at the discretion of building owner or his designate.
- D. Copper metal work should not be used where runoff from the metal work will come into contact with the EcoStar tiles. (Example; ridges or cupolas.)
- E. Underlayment.
  - 1. Glacier Guard
    - a. Lap end joints 6" and side joints 3.5".
    - b. Apply continuous 36" wide sheet in valley centered over valley.
    - c. Apply rows of 36" wide sheets along all eaves and rakes. Lap end joints 6" and side joints 3.5".
    - d. Apply rows of 36" wide sheets along and around all dormers and roof projections. Lap end joints 6" and side joints 3.5".
    - e. When applicable install as far up as it can be installed on any head walls or vertical walls a minimum of 12" when possible.
    - f. Do not leave Glacier Guard Granular Surface exposed to weather more than 30 days after beginning of installation. Do not leave Glacier Guard Smooth Surface exposed to weather more than 30 days after beginning of installation. Do not leave Glacier Guard Smooth Surface High Temp exposed to the weather more than 60 days after the beginning of installation.
    - g. Installation at 40°F or below may require nailing or priming to hold membrane in place while adhesion develops.
  - 2. AquaGuard
    - a. Apply 41.5" wide sheet over complete deck, lapping the area covered with Glacier Guard. Lap end joints 6" and side joints 4" and double through valleys.
    - b. Do not leave exposed to weather more than 90 days after beginning of installation.
    - c. Do not leave any fastener heads exposed. Nail only in areas to be covered by lapping of underlayment.
  - 3. ELK VersaShield
    - a. ELK VersaShield underlayment must be installed over the entire deck surface including over the Glacier Guard in conjunction with EcoStar Class A Seneca tiles for those projects requiring a UL Class A fire rating. ELK VersaShield should be installed per manufacturer's specifications.

## F. Seneca Shake Tile Installation

1. After installing underlayment, and before installing the Seneca Shake Tiles, clean the surface of debris and dirt.
2. Care must be taken to place tiles so color variations are evenly distributed over the entire roof area. Shade variations will occur differently from pallet to pallet and within individual pallets. Tiles between bundles and pallets **MUST** be blended to insure even distribution of color variations. "Mapping" or "Blotching" in appearance is not acceptable and the EcoStar authorized Gold Star applicator will be required to correct. It is recommended that work not begin until **all** EcoStar materials have been delivered to the job site so that **all** the material may be blended together. Periodic ground inspections should be conducted to ensure a random color pattern to the installation. Please contact EcoStar's technical department for correct blending procedures.
3. Minimum Fastening – No less than two EcoStar ring shank fasteners per tile shall be used with a minimum length of 1-1/2". Fasteners should be installed at the designated "nail here" marks on the tile. Failure to fasten the tile at these locations may result in a "lifted" tile that will require removal and replacement.
4. CAUTION: When using a pneumatic nailer, care should be taken to insure that nails are not over driven causing the tiles to curl upward. If tiles have been installed with over driven nails causing the ends of the tile to curve upward, tiles will never lay flat. Overdriven tiles must be removed and re-nailed properly. **Never** hold the tile from behind while nailing, as this will cause an upward curl of the tile.
5. Do not install tiles against each other. A minimum gap of 3/8" must be maintained between installed tiles. A minimum 3/8" gap must be maintained between installed tiles and any sidewalls or roof projections.
6. It is the responsibility of the Gold Star Authorized Applicator to ensure that each Seneca Shake Tile has been flexed to provide a downward curve prior to installation. **Do not install tiles with an upward curve.**
7. Beginning at the eave, install a starter row of Seneca Shake tiles of random width gapped a minimum of 3/8" between tiles and any projections while achieving a 3/4" overhang with two EcoStar ring shank fasteners per tile (in location shown on tiles). This layer of tiles will become the starter row. The final tile at roof edges or penetrations on all courses must be a minimum 3" wide. This may necessitate cutting the tile to fit. To cut the tiles simply score the back of the tile with a straight blade or utility knife and snap along score. Install first layer of tiles of random width flush with the first row ensuring that bond lines are not placed directly over each other.
8. Continue installing rows of tiles of random widths up the roof slope at the correct chosen exposure ensuring that bond lines are not placed directly over each other. It is recommended that chalk lines be placed horizontally up the roof slope. This will ensure that each course is installed parallel with the roof eave. **Never** use red chalk.
9. Valley Areas - either an open or closed valley design may be used.
  - a. With an open valley design leave a minimum of 2" on each side of the center of the valley exposed and uncovered by the roof tiles. A V-Style, W-Style, or Double W-Style Valley metal may be used.
  - b. With a closed valley design cut the tiles in a straight line to fit no closer than 3/8" against tile of adjoining roof slope. Never penetrate valley metal with roof fastener.

10. Install EcoStar EcoVent ridge vent system per the manufacturer's application instructions, and then place the Seneca Shake – Universal Hip/Ridge tile over the ridge vent. A minimum 2.5" stainless steel ring shank, hand-driven EcoStar fastener should be used on a ventilated hip/ridge to fasten the hip/ridge tile to the deck. A minimum 2" stainless steel, hand-driven EcoStar fastener should be used on an unventilated hip/ridge to fasten the hip/ridge tile to the deck. Place fasteners in the location marked on the tile. Seneca Shake – Universal Hip/Ridge Tile **must** be installed with **6"** exposure.
  11. Install the Seneca Shake - Universal Hip/Ridge tile at any hip locations. EcoStar recommends a chalk line be snapped up the hip line to ensure a straight application up the roof slope. Universal Hip/Ridge Tiles **must** be installed with a **6"** exposure.
  12. Seneca Shake Tiles may not be installed if the tiles have been stored in temperatures lower than 45°F. If tiles have been stored in temperatures below 45°F, tiles must be brought back to a material temperature of 45°F. As the temperature rises Seneca Shake Tiles will expand beyond the designed installation pattern if the product is installed while cold or frozen.
  13. Care must be taken to minimize foot traffic over completed areas of the roof. Seneca Cedar Shake Tiles will show mud and dirt causing appearance problems. The removal of dirt and debris is the responsibility of the applicator. Never use chemical cleaning agents, not approved by EcoStar, to wash an EcoStar roof assembly.
  14. Seneca Shake Tiles can be slippery when wet; caution should be exhibited with early morning dew and after rain. EcoStar recommends the use of toe boards and OSHA approved harnesses and safety equipment at all time.
  15. Upon completion of the roof system installation, inspect and remove all debris from roof.
- F. Phased Roofing - The weathering process of the EcoStar tiles will begin immediately upon installation and exposure to the elements. Therefore, every effort should be made to ensure that the EcoStar roof assembly is installed at a continuous rate to completion. Lengthy delays in installation may result in appearance differences when installation is resumed and tiles that have not been exposed to the elements are installed adjacent to tiles that have been on the roof for an extended period of time.